







































































Original	Substituto	Original	Substituto
 Power	 Power	 EPG	 Guide
 1	 1	 FAV	 Shift + Pre Ch
 2	 2	 Presets	 Media
 3	 3	 [≡]/Text	 Text
 4	 4	 Mute	 Mute
 5	 5	 Source	 AV
 6	 6	 Menu	 Menu
 7	 7	 Info/?	 Info
 8	 8	 Return	 Back
 9	 9	 OK	 Ok
 0	 0	 Up	 Up
 Recall	 Pre Ch	 Down	 Down
 Sleep	 Sleep	 Right	 Right
 Screen	 Format	 Left	 Left
 Lang	 Dual	 Vol-	 Vol -
 Subttl	 Subt	 Vol+	 Vol +
 PIP	 3D	 P+	 Ch +





Original		Substituto		Original		Substituto	
	P-		Ch -				
	Red/Up		Red				
	Green/Down		Green				
	Yellow		Yellow				
	Blue		Blue				

