































































Original	Substituto
	 Power
	 Yellow / YouTube / Repeat
	 Exit / Cancel / Clear
	 Eject / Surround
	 Sleep / Timer
	 Shift + Pause / Step /
	 TV/Radio /
	 Mute / Dimmer
	 1
	 2
	 3
	 Audio / Lang I/II
	 4
	 5
	 6
	 Subtitle / EQ
	 7

Original	Substituto
	 8
	 9
	 Zoom / Size
	 0
	 Guide / EPG / -/-
	 Blue / Prime Video / Random
	 Display / Media
	 Back / Return
	 Green / APP / Repeat
	 Menu / Home
	 Vol+
	 Info / Angle
	 Shift + Eject / Surround
	 Shift + Play /
	 Vol-
	 Setup / OPT /
	 Up





Original	Substituto	Original	Substituto
	L/R		D.Menu / Top
	Left		Left
	Enter		OK
	Right		Right
	Stop		Stop / Hold
	Down		Down
	Play		Play / Slow
	N/P		Picture / Format
	PBC		Smart / List
	Title		Sound / Title
	Pause/Step		Pause / Step / Freeze
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	<<		<< / Tune-
	>>		>> / Tune+

