



Original	Substituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 TXT	 Text / Goto
 0	 0
 i	 Info / Angle
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 Vol-	 Vol-

Original	Substituto
 Source	 AV / Input / RDS
 P-	 CH- / Page-
 Smart	 Smart / List
 Guide	 Guide / EPG / -/-
 *	 Menu / Home
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Back	 Back / Return
 Exit	 Exit / Cancel / Clear
 Netflix	 Shift + Red / Netflix /
 YouTube	 Shift + Yellow / YouTube /
 prime video	 Shift + Blue / Prime
 Disney+	 TV/Radio /
 Internet	 Display / Media





Original	Substituto
	FPay
	Red
	Green
	Yellow
	Blue
	<<
	Stop
	>>
	Rec
	Play
	Pause

Original	Substituto

