







































































Original		Substituto		Original		Substituto	
	Power		Power		EPG		Guide
	1		1		FAV		Shift + Pre Ch
	2		2		Presets		Media
	3		3		[≡]/Text		Text
	4		4		Mute		Mute
	5		5		Source		AV
	6		6		Menu		Menu
	7		7		Info/?		Info
	8		8		Return		Back
	9		9		OK		Ok
	0		0		Up		Up
	Recall		Pre Ch		Down		Down
	Sleep		Sleep		Right		Right
	Screen		Format		Left		Left
	Lang		Dual		Vol-		Vol -
	Subttl		Subt		Vol+		Vol +
	PIP		3D		P+		Ch +





Original	Substituto	Original	Substituto
P-	Ch -		
Red/Up	Red		
Green/Down	Green		
Yellow	Yellow		
Blue	Blue		

