







































































Original	Substituto	Original	Substituto
 Power	 Power	 PR-	 Ch -
 Source	 AV	 Mute	 Mute
 1	 1	 Ch.List	 List
 2	 2	 Media.P	 Media
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Enter	 Ok
 0	 0	 Up	 Up
 TTX/MIX	 Text	 Down	 Down
 PRE-CH	 Pre Ch	 Right	 Right
 Vol+	 Vol +	 Left	 Left
 Vol-	 Vol -	 Red	 Red
 PR+	 Ch +	 Green	 Green





Original	Substituto
 Yellow	 Yellow
 Blue	 Blue
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Dual I/II	 Dual
 AD	 Shift + Subt
 P.Size	 Format
 Subt.	 Subt
 <<	 <<
 Pause	 Pause
 >>	 >>
 Rec	 Rec
 Play	 Play
 Stop	 Stop

Original	Substituto

