





















































| Original | Substituto | Original | Substituto |
|---|------------|---|--------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  | Guide / EPG / -/-- |
|  | AV |  | AV / Input / RDS |
|  | Menu |  | Menu / Home |
|  | Swap |  | Back / Return |
|  | OK |  | OK |

| Original | Substituto | Original | Substituto |
|---|--------------------|---|-----------------------------|
|  | Up |  | Up |
|  | PR+ |  | CH+ / Page+ |
|  | PR- |  | CH- / Page- |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Vol+ |  | Vol+ |
|  | Left |  | Left |
|  | Vol- |  | Vol- |
|  | TV/TX |  | Text / Goto |
|  | PP |  | Fav / Marker / PC |
|  | 16:9 |  | Setup / OPT / |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | Violet |  | Display / Media |
|  | [] Smart Controls |  | Picture / Format |





| Original | Substituto |
|--|---|
|  Smart Controls |  Sound / Title |
|  MIX/))>((|  Audio / Lang I/II |
|  P100/PAT |  Sleep / Timer |
|  SUB |  Subtitle / EQ |
|  Update |  Zoom / Size |
|  Hold |  Stop / Hold |
|  Doub/Freeze |  Eject / Surround |
|  REV/Scan |  TV/Radio / |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

