











































































Original	Substituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv/Radio	 TV/R
 EPG	 Guide
 Menu	 Menu
 Exit	 Exit
 OK/List	 Ok

Original	Substituto
 ←PR	 Back
 FAV	 Pre Ch
 Up	 Up
 PR+	 Ch +
 PR-	 Ch -
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Find	 Red
 Green/Zoom	 Green
 Yellow	 Yellow
 Text	 Text
 Blue	 Blue
 Audio L/R	 Dual
 Info	 Info





	Original	Substituto	Original	Substituto
	Tv/AV	 AV		
	Sleep	 Sleep		
	[+]	 Options		
	Record	 Rec		
	Play	 Play		
	Stop	 Stop		
	Shift	 Media		
	<< Fast	 <<		
	Fast >>	 >>		
	< Slow	 I<<		
	Slow >	 >>I		
	Pause	 Pause		
	↑/Page+	 3D		
	↓/Page-	 Format		

