



































































Original	Substituto	Original	Substituto
	Power		Power
	⊖		Sleep
	Exit		Exit
	I-II		Dual
	I.S.		Smart
	[i+]		Info
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Smart Audio		Shift + Dual
	Smart Picture		Format
	Menu		Menu
	Text / OK		Ok
	Text / OK		Text
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	P +		Ch +
	P -		Ch -
	Red / Rec		Red
	Red / Rec		Rec
	Green / <<		Green
	Green / <<		<<





Original	Substituto	Original	Substituto
 Yellow / Stop	 Yellow		
 Yellow / Stop	 Stop		
 Blue / Play	 Blue		
 Blue / Play	 Play		
 [X]	 SHIFT +  CLEAR Exit		
 [◆] /  ⊕	 3D		
 [□] /  >>>	 SHIFT +  Stop		
 [□] /  >>>	 >>>		
 [/≡]	 SHIFT +  REPEAT Text		
 [?]	 SEARCH TV/R		
 [≡i]	 GUIDE		

