



























































Original	Substituto	Original	Substituto
 Power	 Power	 Up	 Up
 D/A Tv	 Smart	 Down	 Down
 Input	 AV	 Right	 Right
 Guide	 Guide	 Left	 Left
 Radio	 TV/R	 OK	 Ok
 Subtitle/*	 Subt	 Red	 Red
 PIP PR-	 Shift + Ch +	 Green	 Green
 PIP PR+	 Shift + Ch -	 Yellow	 Yellow
 Swap	 Media	 Blue	 Blue
 PIP Input	 Shift + AV	 Vol+	 Vol +
 PIP	 Shift + 3D	 Vol-	 Vol -
 Info	 Info	 Mute	 Mute
 Back	 Back	 FAV	 Pre Ch
 ARC	 3D	 CH+	 Ch +
 Menu	 Menu	 CH-	 Ch -
 Text	 Text	 1	 1
 Exit	 Exit	 2	 2

Original	Substituto	Original	Substituto
 Up	 Up	 TV	 AUX
 Down	 Down	 DVD	 SAT
 Right	 Right	 PLAY MODE	 REC MODE
 Left	 Left	 STOP	 STOP
 OK	 Ok	 LEFT NAV	 RIGHT NAV
 Red	 Red	 DISC NAV	 SOUND
 Green	 Green	 LIST	 AD
 Yellow	 Yellow	 DUAL	 SUBT
 Blue	 Blue	 SEARCH	 PICTURE
 Vol+	 Vol +	 SLEEP	 FORMAT
 Vol-	 Vol -	 TV/R	 3D
 Mute	 Mute	 E-MANUAL	 TIMER
 FAV	 Pre Ch	 REPEAT	 ZOOM
 CH+	 Ch +	 D.MENU	 TEXT
 CH-	 Ch -	 TOP MENU	 AV
 1	 1	 DISPLAY	 MUTE
 2	 2	 MENU	 INFO





Original		Substituto		Original		Substituto	
	3		3		Sleep		Sleep
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	List		List				
	Q.View		D. Menu				
	[≡♦]/Size		Format				
	[≡X]/Position		Eject				
	[≡i]/Scan/Index		Shift + Info				
	[≡o]/Time		Shift + Text				
	[≡?]/Reveal		Options				
	[≡+]/Hold		Shift + Subt				
	I/II		Dual				









































Original	Substituto	Original	Substituto
	Power		Power
	Menu		Menu
	Up		Up
	OK		Ok
	Down		Down
	Right		Right
	Left		Left
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Original	Substituto	Original	Substituto
	Play		Play
	Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>
	<<		<<
	>>		>>





	Original	Substituto	Original	Substituto
	Power			Rec
	Input			<<
	CH+			>>
	CH-			
	1			
	2			
	3			
	4			
	5			
	6			
	7			
	8			
	9			
	0			
	Play			
	Pause			
	Stop	