







































































| Original | Substituto | Original | Substituto |
|---|------------|---|-----------------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Lang |  | Audio / Lang I/II |
|  | [=].. |  | Subtitle / EQ |
|  | Mute |  | Mute / Dimmer |
|  | Home |  | Shift + Menu / |
|  | Smart |  | Smart / List |
|  | Vol+ |  | Vol+ |
|  | Vol- |  | Vol- |
|  | P+ |  | CH+ / Page+ |
|  | P- |  | CH- / Page- |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | OK |
|  | [G] |  | Guide / EPG / -/-- |
|  | i |  | Info / Angle |
|  | ← |  | Back / Return |
|  | Exit |  | Exit / Cancel / Clear |
|  | Menu |  | Menu / Home |
|  | Source |  | AV / Input / RDS |
|  | Text |  | Text / Goto |
|  | << |  | << / Tune- |
|  | Stop |  | Stop / Hold |





| Original | Substituto | Original | Substituto |
|-------------|-----------------------------|----------|------------|
| >> | >> / Tune+ | | |
| Rec | Rec / Rec Mode | | |
| Pause | Pause / Step / Freeze | | |
| Play | Play / Slow | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| Netflix | Shift + Red / Netflix / | | |
| YouTube | Shift + Yellow / YouTube / | | |
| prime video | Shift + Blue / Prime | | |
| Google Play | Display / Media | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

