



































































Original	Substituto	Original	Substituto
	Power		Power
	Premium On		Smart
	Guida		Guide
	Menu		Menu
	Info		Info
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Back		Back
	Exit		Exit
	Stop		Stop
	Play		Play
	Pause		Pause
	>>		>>
	<<		<<
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Lista		List
	Opzioni		Options
	Red		Red





Original	Substituto	Original	Substituto
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 APP	 Media		
 Recall	 Pre Ch		

