



















































Original	Substituto	Original	Substituto
 Power	 Power	 Red	 Red / Netflix / Search
 DVB Menu	 D.Menu / Top	 Tv/Radio	 TV/Radio /
 Open/Close	 Eject / Surround	 >>	 >> / Tune+
 Prog+	 CH+ / Page+	 Green/Audio	 Green / APP / Repeat
 Prog-	 CH- / Page-	 I<<	 I<< / Preset-
 Exit	 Exit / Cancel / Clear	 Yellow/Freeze	 Yellow / YouTube / Repeat
 Play	 Play / Slow	 >>I	 >>I / Preset+
 Pause	 Pause / Step / Freeze	 Blue/Subtitle	 Blue / Prime Video / Random
 TV/TXT/Tv Format	 Shift + Text /	 CH+	 Shift + CH+ /
 Cancel/Text	 Shift + Exit / Cancel / Clear	 Tv-Menu	 Shift + Menu /
 Reveal/Info	 Shift + Info / Angle	 Vol+	 Vol+
 Stop	 Stop / Hold	 CH-	 Shift + CH- /
 Hold/Language	 Shift + Stop /	 Tv/AV	 AV / Input / RDS
 Size/FAV	 Shift + Zoom /	 Vol-	 Vol-
 Subpage/EPG	 Shift + Guide / EPG / -/-	 +5V	 Shift + 5
 Index	 Setup / OPT /	 Sleep	 Sleep / Timer
 <<	 << / Tune-	 Up	 Up





Original	Substituto	Original	Substituto
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Mute		Mute / Dimmer
	Display		Display / Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Guide / EPG / /--		Guide / EPG / /--
	0		0
	Recall		Back / Return
	Picture		Picture / Format
	Sound		Sound / Title
	Nicam/A2		Shift + Picture / Format
	Language		Audio / Lang I/II
	Zoom		Zoom / Size
	DVD-Setup		Shift + 2
	Menu		Menu / Home
	Subtitle		Subtitle / EQ
	Program		Shift + TV/Radio / Program
	Angle		Info / Angle
	Title		Shift + Sound / Title
	Goto		Text / Goto
	Slow		Shift + Play /
	Repeat		Shift + Back / Return
	A-B		Shift + Yellow / YouTube /

