






































| Original | Substituto |
|--|---|
|  Power |  Power |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  TV/SAT |  AV / Input / RDS |
|  TV/Radio |  TV/Radio / |
|  Zoom |  Zoom / Size |
|  List |  Smart / List |
|  Audio |  Audio / Lang I/II |
|  EPG |  Guide / EPG / -/-- |
|  Timer |  Sleep / Timer |
|  Text |  Text / Goto |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  M/P |  Display / Media |
|  Mute |  Mute / Dimmer |

| Original | Substituto |
|--|---|
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  OK |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Recall |  Back / Return |
|  P+ |  >> / Preset+ |
|  P- |  << / Preset- |
|  FAV |  Fav / Marker / PC |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |





| Original | | Substituto | | Original | | Substituto | |
|----------|-------|---------------------|-----------------------|----------|--|------------|--|
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| 0 | 0 | HDMI - BAT 0 | 0 | | | | |
| INFO | Info | ANGLE INFO | Info / Angle | | | | |
| PAUSE | Pause | STEP - FREEZE II | Pause / Step / Freeze | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |





| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |




































| Original | Substituto |
|-------------------|---------------------------|
| Yellow / Subtitle | Yellow / YouTube / Repeat |
| Yellow / Subtitle | Subtitle / EQ |
| TV / AV | AV / Input / RDS |
| Green / P/N | Green / APP / Repeat |
| TV / Radio | TV/Radio / |
| SAT | Shift + 0 |
| EPG | Guide / EPG / -/-- |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| Original | Substituto | Original | Substituto |
|------------|---|--------------|--|
| Mute |  Mute / Dimmer | Menu Down |  Down |
| PWR On/Off |  Power | Back |  Back / Return |
| App |  +  Shift + Green / APP / | Volume+ |  Vol+ |
| Epg |  Guide / EPG / -/-- | CH/Page+ |  CH+ / Page+ |
| Info |  Info / Angle | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | CH/Page- |  CH- / Page- |
| TV |  TV/Radio / | Audio |  Audio / Lang I/II |
| Text |  Text / Goto | 1. ? |  1 |
| Zoom |  Zoom / Size | 2abc |  2 |
| Menu |  Menu / Home | 3def |  3 |
| TV/SAT |  AV / Input / RDS | 4ghi |  4 |
| Menu Up |  Up | 5jkl |  5 |
| Display |  Display / Media | 6mno |  6 |
| Menu Left |  Left | 7pqrm |  7 |
| OK Enter |  OK | 8tuv |  8 |
| Menu Right |  Right | 9wxyz |  9 |
| Exit |  Exit / Cancel / Clear | Guide Pilote |  +  Shift + Guide / EPG / -/-- |



























































| Original | Substituto | Original | Substituto |
|-----------|-----------------------------|----------|------------|
| 0/10 | 0 | | |
| FAV Pref. | Fav / Marker / PC | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| Dec/Pause | Pause / Step / Freeze | | |
| | Smart / List | | |
| | D.Menu / Top | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |











| Original | Substituto | Original | Substituto |
|----------|---|----------|---|
| Power |  Power | Recall |  Back / Return |
| Mute |  Mute / Dimmer | Vol+ |  Vol+ |
| Pause |  Pause / Step / Freeze | List |  Smart / List |
| Audio |  Audio / Lang I/II | P+ |  CH+ / Page+ |
| Zoom |  Zoom / Size | Vol- |  Vol- |
| Timer |  Sleep / Timer | M/P |  Display / Media |
| Tv/Radio |  TV/Radio / | P- |  CH- / Page- |
| Text |  Text / Goto | 1 |  1 |
| Tv/SAT |  AV / Input / RDS | 2 |  2 |
| Menu |  Menu / Home | 3 |  3 |
| Up/CH+ |  Up | 4 |  4 |
| Info |  Info / Angle | 5 |  5 |
| Left |  Left | 6 |  6 |
| OK |  OK | 7 |  7 |
| Right |  Right | 8 |  8 |
| Exit |  Exit / Cancel / Clear | 9 |  9 |
| Down/CH- |  Down | EPG |  Guide / EPG / -/- |

| Original | Substituto | Original | Substituto |
|----------|---|----------|---|
| Power |  Power | Recall |  Back / Return |
| Mute |  Mute / Dimmer | Vol+ |  Vol+ |
| Pause |  Pause / Step / Freeze | List |  Smart / List |
| Audio |  Audio / Lang I/II | P+ |  CH+ / Page+ |
| Zoom |  Zoom / Size | Vol- |  Vol- |
| Timer |  Sleep / Timer | M/P |  Display / Media |
| Tv/Radio |  TV/Radio / | P- |  CH- / Page- |
| Text |  Text / Goto | 1 |  1 |
| Tv/SAT |  AV / Input / RDS | 2 |  2 |
| Menu |  Menu / Home | 3 |  3 |
| Up/CH+ |  Up | 4 |  4 |
| Info |  Info / Angle | 5 |  5 |
| Left |  Left | 6 |  6 |
| OK |  OK | 7 |  7 |
| Right |  Right | 8 |  8 |
| Exit |  Exit / Cancel / Clear | 9 |  9 |
| Down/CH- |  Down | EPG |  Guide / EPG / -/- |





| Original | Substituto | |
|--------------|---|---|
| 0/Sleeptimer |  0 | 0 |
| FAV |  Fav / Marker / PC | |
| Red |  Red / Netflix / Search | |
| Green |  Green / APP / Repeat | |
| Yellow |  Yellow / YouTube / Repeat | |
| Blue |  Blue / Prime Video / Random | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

