






Original	Substituto
	Mute
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	REC / Rec Mode
	0
	AV / Input / RDS
	Setup / OPT /
	<< / Tune-
	Red / Netflix / Search

Original	Substituto
	Green / Stop
	Green / APP / Repeat
	Play / Slow
	Yellow / YouTube / Repeat
	Picture / Format
	Blue / Prime Video / Random
	>> / Tune+
	Up
	Left
	OK
	Right
	Down
	Guide / EPG / -/-
	Exit / Cancel / Clear
	Back / Return
	Info / Angle
	CH+ / Page+








Original	Substituto
	Mute / Dimmer
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	REC / Rec Mode
	AV / Input / RDS
	0
	Setup / OPT /
	<< / Tune-
	Red / Netflix / Search

Original	Substituto
	Green / APP / Repeat
	Stop / Hold
	Play / Slow
	Yellow / YouTube / Repeat
	>> / Tune+
	Picture / Format
	Blue / Prime Video / Random
	Up
	Left
	OK
	Right
	Down
	Guide / EPG / -/-
	Exit / Cancel / Clear
	Back / Return
	Info / Angle
	CH+ / Page+





Original	Substituto
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 REC	 Rec / Rec Mode
 0 / AV	 AV / Input / RDS
 0 / AV	 0
 OPT	 Setup / OPT /
 Red / <<	 Red / Netflix / Search
 Red / <<	 << / Tune-

Original	Substituto
 Green / Stop	 Green / APP / Repeat
 Green / Stop	 Stop / Hold
 Yellow /	 Play / Slow
 Yellow /	 Yellow / YouTube / Repeat
 Blue / >> /	 Blue / Prime Video / Random
 Blue / >> /	 Picture / Format
 Blue / >> /	 >> / Tune+
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 SFI / EPG	 Guide / EPG / -/-
 Exit / Recall	 Exit / Cancel / Clear
 Exit / Recall	 Back / Return
 Info	 Info / Angle
 Prog +	 CH+ / Page+



