







Original	Substituto	Original	Substituto
 Power	 Power	 OK	 Ok
 Mute	 Mute	 Right	 Right
 1	 1	 Down	 Down
 2	 2	 Retour	 Back
 3	 3	 Quitter	 Exit
 4	 4	 Info	 Info
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 ↑	 Shift + Ch +
 8	 8	 ↓	 Shift + Ch -
 9	 9	 Ch+	 Ch +
 0	 0	 Ch-	 Ch -
 HD	 Media	 Menu	 Menu
 VOD	 Smart	 Radio	 TV/R
 Guide	 Guide	 Red	 Red
 Up	 Up	 Green	 Green
 Left	 Left	 Yellow / Fav	 Yellow





Original	Substituto	Original	Substituto
 Yellow / Fav	 Pre Ch		
 Blue / Text	 Blue		
 Blue / Text	 Text		
 <<	 <<		
 Stop	 Stop		
 Pause / Play	 Play		
 Pause / Play	 Pause		
 >>	 >>		
 Rec	 Rec		
 Rec TV	 List		

