










Original	Substituto	Original	Substituto
	Power		Power
	Home / IPTV		Smart
	TV		TV/R
	USB		Media
	Internet		Shift + Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Aspect		Format
	Recall		Pre Ch
	Menu		Menu
	Source		AV
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right
	Down		Down
	Exit		Exit
	Info		Info
	CH+		Ch +
	CH-		Ch -
	Mute		Mute
	Picture		Shift + Format
	Vol+		Vol +
	Vol-		Vol -
	Red / <<		Red
	Red / <<		<<





Original	Substituto
Green / >>>	Green
Green / >>>	>>>
Yellow / I<<<	Yellow
Yellow / I<<<	I<<<
Blue / >>>	Blue
Blue / >>>	>>>
[=] / Play/Pause	Text
[=] / Play/Pause	Play
[=] / Play/Pause	Pause
[=?] / Stop	Stop
[=□] / Repeat	Shift + Text
[=↑] / Sleep	Sleep
[=i] / EPG	Guide
[=⊙] / Subtitle	Subt
Audio I/II	Dual
Sound	Shift + Dual
PVR	Options

Original	Substituto

