





































Original	Substituto
 Standby	 Power
 DTV / VCR	 AV / Input / RDS
 Mute	 Mute / Dimmer
 Menu	 Menu / Home
 Info	 Info / Angle
 EPG	 Guide / EPG / /--
 Pause	 Pause / Step / Freeze
 Stop / Exit	 Exit / Cancel / Clear
 Stop / Exit	 Stop / Hold
 Up / CH+ / Prev	 Up
 Up / CH+ / Prev	 CH+ / Page+
 Up / CH+ / Prev	 I<< / Preset-
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 OK	 OK
 Right / Vol+	 Right
 Right / Vol+	 Vol+

Original	Substituto
 Down / CH- / Next	 Down
 Down / CH- / Next	 >>I / Preset+
 Down / CH- / Next	 CH- / Page-
 Favorite	 Fav / Marker / PC
 Timer	 Sleep / Timer
 Recall	 Back / Return
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV / Radio	 TV/Radio /





Original	Substituto	Original	Substituto
Audio	Audio / Lang I/II		
Subtitle	Subtitle / EQ		
Text	Text / Goto		
Red / Album	Red / Netflix / Search		
Green / Music	Green / APP / Repeat		
Yellow / Movie	Yellow / YouTube / Repeat		
Blue / Multiscn	Blue / Prime Video / Random		

Original	Substituto

