







































































Original	Substituto	Original	Substituto
	Power		Power
	Open / Close		Eject
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Audio		Dual
	Subtitle		Subt
	Angle		Format
	Menu		Menu
	Title		Smart
	[]		Media
	Exit		Exit
	Up / >>>		>>>
	Up / >>>		Up
	Left		Left
	OK / Play		Ok
	OK / Play		Play
	Right		Right
	Down / <<<		<<<
	Down / <<<		Down
	>>> / >>>I		>>>I
	>>> / >>>I		Ch +
	<<< / <<<I		<<<I
	<<< / <<<I		Ch -
	Stop		Stop
	Pause		Pause



