



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--	+	Shift + Guide
	Back		Back
	P.Mode	+	Shift + Format
	S.Mode		Dual
	Sleep		Sleep

Original	Substituto	Original	Substituto
	Vol+		Vol +
	Vol-		Vol -
	Aspect		Format
	CH+		Ch +
	CH-		Ch -
	MTS		Media
	Set		Pre Ch
	Home		Smart
	Mouse		TV/R
	Menu		Menu
	Source		AV
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right
	Down		Down
	Exit		Exit





Original	Substituto	Original	Substituto
 Display	 Info	 Hold	 Shift + Stop
 Red	 Red	 Mix	 Shift + Text
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 << / Text	 <<		
 << / Text	 Text		
 Play/Pause /	 Play		
 Play/Pause /	 Pause		
 >> / Reveal	 >>		
 I<< / Cancel	 I<<		
 >>I / Freeze	 >>I		
 Stop / Index	 Stop		
 EPG	 Guide		
 Rec	 Rec		
 Sub-T	 Subt		
 Size	 Eject		

