









Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Last View		Pre Ch
	Radio/Tv		TV/R
	Internet		Smart
	Netflix		Media
	Rec		Rec
	Prog/Check		Sleep

Original	Substituto	Original	Substituto
	Play		Play
	>>		>>
	<<		<<
	Pause		Pause
	>>		>>
	<<		<<
	Stop		Stop
	Exit		Exit
	i/Status		Info
	Return		Back
	Guide		Guide
	Function Menu		Menu
	Video Menu		D. Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left





Original	Substituto
 OK	 Ok
 Option	 Options
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Audio	 Dual
 Drive Select	 List
 Text	 Text
 STTL	 Subt
 +60s	 3D
 -10s	 Format
 Page/CH+	 Ch +
 Page/CH-	 Ch -
 Tv Vol+	 Vol +
 Tv Vol-	 Vol -
 AV Input Tv	 AV

Original	Substituto
 CH+ Tv	 Shift + Ch +
 CH- Tv	 Shift + Ch -
 Power Tv	 Shift + Power

