








Original	Substituto
 Standby	 Power
 Auto Setup	 Auto
 Computer	 Vol - / Page -
 Video	 Shift + Video Comp <small>Shift + Comp / Video</small>
 S-Video	 Vol + / Page +
 Component	 Video Comp <small>Comp / Video</small>
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 SELECT	 Enter
 MENU	 Menu
 SCREEN	 Aspect Eco <small>Eco / Aspect</small>
 KEYSTONE	 Shift + Up <small>Shift + Up</small>
 INFO	 Info Help <small>Help / Info</small>
 FREEZE	 Timer Freeze <small>Freeze / Timer</small>
 BLANK	 Mute Blank <small>Blank / Mute</small>

Original	Substituto
 P-Timer	 Shift + Timer Freeze <small>Shift + Freeze / Timer</small>
 LAMP	 Mode
 IMAGE	 Invert 3D <small>3D / Invert</small>
 D.ZOOM +	 Play <small>+ / Play</small>
 D.ZOOM -	 Stop <small>- / Stop</small>

