















Original	Substituto	Original	Substituto
	Power		Power
	Source		AV
	blank		TV/R
	[> <]		Options
	square		D. Menu
	Red / Rec / Movie		Red
	Red / Rec / Movie		Rec
	Green / << /		Green
	Green / << /		<<
	Yellow / Stop / Child		Yellow
	Yellow / Stop / Child		Stop
	Blue / Play / News		Blue
	Blue / Play / News		Play
	>> / Other		>>
	Guide		Guide
	Text		Text
	Up		Up

Original	Substituto	Original	Substituto
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu		Menu
	V +		Vol +
	V -		Vol -
	Mute		Mute
	P +		Ch +
	P -		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7







































































Original		Substituto	
	8		8
	9		9
	0		0
	i+		Info
	P < P / -/--		Pre Ch
	Smart Sound		Shift + Media
	Active Control		Smart
	Smart Picture		Media
	[1 2]		3D
	[< >]		Subt
	[]		Exit
	small squares		Sleep
	Timer		Shift + AV
	[?]		Back
	Zoom		Eject
	I-II		Dual
	Instant Rec		Shift + Rec

Original		Substituto	
	Format		Format
	DNR		List
	Instant Stop		Shift + Stop





Original	Substituto	Original	Substituto
	Power		Power
	Rec		Rec
	<<		<<
	<<		I<<
	Stop		Stop
	Play		Play
	>>		>>
	>>		>>I
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Text		Text
	Menu		Menu
	P +		Ch +
	P -		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	i+		Info
	P < P / -/--		Pre Ch
	Timer		AV
	[?]		D. Menu
	Zoom		Eject
	I / II		Dual

