



















































Original	Substituto	Original	Substituto
	Power		Power
	Coax		1
	Optical		3
	Aux		4
	Audio In		6
	USB		Guide
	Bluetooth		0
	HDMI ARC		Pre Ch
	I<		I<<
	Play/Pause		Play
	I>		>>I
	Bass+		Up
	Bass-		Down
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Treble+		Ch +

Original	Substituto	Original	Substituto
	Treble-		Ch -
	Sound		Dual
	Surround On		Smart
	Surround Off		Media
	Audio Sync +		Right
	Audio Sync -		Left
	Night		Info
	DIM		D. Menu

