







































































| Original | Substituto | Original | Substituto |
|--|--|--|---|
|  Power DVD |  Power |  A-B/Repeat |  Options |
|  Display |  Info |  Clear |  Exit |
|  SYS Video |  Back |  FTS/Program |  Sleep |
|  On/Off PBC |  Media |  Menu System |  Menu |
|  1 |  1 |  Menu Disc |  D. Menu |
|  2 |  2 |  Up |  Up |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  Right |  Right |
|  5 |  5 |  Left |  Left |
|  6 |  6 |  OK |  Ok |
|  7 |  7 |  Stop/Return |  Stop |
|  8 |  8 |  Play |  Play |
|  9 |  9 |  Pause |  Pause |
|  0 |  0 |  >> |  >> |
|  +10 |  Guide |  << |  << |
|  Title |  Pre Ch |  > |  >> |
|  Repeat |  Text |  < |  << |



