







































































Original	Substituto	Original	Substituto
 Standby - On	 Power	 CH-	 Ch -
 1	 1	 Down	 Down
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 Play	 Play
 6	 6	 Select	 Info
 7	 7	 Edit	 TV/R
 8	 8	 Stop	 Stop
 9	 9	 Rec	 Rec
 0	 0	 Pause	 Pause
 Browser	 Smart	 I<<	 I<<
 Timer	 Sleep	 >>I	 >>I
 Menu System	 Menu	 Return	 Back
 Menu Disc	 D. Menu	 Red	 Red
 Up	 Up	 Green	 Green
 CH+	 Ch +	 Yellow	 Yellow

Original	Substituto	Original	Substituto
 Standby - On	 Power	 CH-	 Ch -
 1	 1	 Down	 Down
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 Play	 Play
 6	 6	 Select	 Info
 7	 7	 Edit	 TV/R
 8	 8	 Stop	 Stop
 9	 9	 Rec	 Rec
 0	 0	 Pause	 Pause
 Browser	 Smart	 I<<	 I<<
 Timer	 Sleep	 >>I	 >>I
 Menu System	 Menu	 Return	 Back
 Menu Disc	 D. Menu	 Red	 Red
 Up	 Up	 Green	 Green
 CH+	 Ch +	 Yellow	 Yellow





Original	Substituto	Original	Substituto
Standby - On	Power	Rec	Rec
1	1	Return	Back
2	2	Red	Red
3	3	Green	Green
4	4	Yellow	Yellow
5	5	Blue	Blue
6	6	Tuner	Subt
7	7	T/C	Guide
8	8	Tv Vol+	Vol +
9	9	Tv Vol-	Vol -
0	0	TV / DVD	TV/R
Timer	Sleep	Menu System	Menu
Up	Up		
CH+	Ch +		
CH-	Ch -		
Down	Down		
OK	Ok		

Original	Substituto	Original	Substituto
Standby - On	Power	Rec	Rec
1	1	Return	Back
2	2	Red	Red
3	3	Green	Green
4	4	Yellow	Yellow
5	5	Blue	Blue
6	6	Tuner	Subt
7	7	T/C	Guide
8	8	Tv Vol+	Vol +
9	9	Tv Vol-	Vol -
0	0	TV / DVD	TV/R
Timer	Sleep	Menu System	Menu
Up	Up		
CH+	Ch +		
CH-	Ch -		
Down	Down		
OK	Ok		

