


































Original	Substituto	Original	Substituto
	Input / RDS		Left
	Power		Right
	Shift + 4		OK
	Shift + 2		Down
	Shift + 5		Menu / Home
	Shift + 7		Vol+
	Picture / Format		CH+ / Page+
	Shift + Zoom /		Vol-
	Subtitle / EQ		Mute / Dimmer
	Red / Netflix / Search		CH- / Page-
	Green / APP / Repeat		1
	Yellow / YouTube / Repeat		2
	Blue / Prime Video / Random		3
>>/Pixel Plus button"/>	>> / Tune+		4
	Guide / EPG / -/--		5
	Up		6
	Text / Goto		7





	Original	Substituto	Original	Substituto
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P	 Fav / Marker / PC		
	♪ Smart	 Sound / Title		
	[-o-]/Active Control	 D.Menu / Top		
	[] Smart	 Smart / List		
	[o]	 TV/Radio /		
	Setup	 Setup / OPT /		
	[+]	 Display / Media		
	[♦]/Zoom	 Zoom / Size		
	[]	 Audio / Lang I/II		
	Instant	 Back / Return		
	[<>]	 Sleep / Timer		
	[↔]	 Eject / Surround		






Original	Substituto
	AV / Input / RDS
	Power
	Shift + 4
	Shift + 2
	Shift + 5
	Shift + 7
	Zoom / Size
	Subtitle / EQ
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	>> / Tune+
	Guide / EPG / -/-
	Up
	Text / Goto
	Left

Original	Substituto
	Right
	OK
	Down
	Menu / Home
	Vol+
	CH+ / Page+
	Vol-
	Mute / Dimmer
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8








































































Original	Substituto
	AV / Input / RDS
	Power
	Shift + 4
	Shift + 2
	Shift + 5
	Shift + 7
	Zoom / Size
	Subtitle / EQ
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	>> / Tune+
	Guide / EPG / -/-
	Up
	Text / Goto
	Left

Original	Substituto
	Right
	OK
	Down
	Menu / Home
	Vol+
	CH+ / Page+
	Vol-
	Mute / Dimmer
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8





Original	Substituto	Original	Substituto
	Input		AV / Input / RDS
	Power		Power
	VCR		Shift + 4
	DVD		Shift + 2
	AMP		Shift + 5
	AUX		Shift + 7
	[...]		Subtitle / EQ
	Green/<</Sport		Green / APP / Repeat
	>>/Pixel Plus		>> / Tune+
	Guide		Guide / EPG / -/--
	Up		Up
	[=]		Text / Goto
	Left		Left
	Right		Right
	OK		OK
	Down		Down
	Menu		Menu / Home
	Vol+		Vol+
	P+		CH+ / Page+
	Vol-		Vol-
	Mute		Mute / Dimmer
	P-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Fav / Marker / PC

