





































































Original	Substituto	Original	Substituto
 Power On/Off	 Power	 I-II MTS	 Dual
 Display	 Info	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Integrator	 Smart
 3	 3	 Home	 Menu
 4	 4	 Exit	 Exit
 5	 5	 Return	 Back
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter/Set	 Ok
 CH Enter	 Pre Ch	 Red	 Red
 P/CH+	 Ch +	 Green	 Green
 P/CH-	 Ch -	 Yellow	 Yellow
 Muting	 Mute	 Blue	 Blue
		 PC	 Media









































































Original	Substituto
Input	AV
Ext Input	Shift + AV
TV	TV/R
Split	Shift + 3D
Sub Input	Subt
Swap	Sleep
(PIP) Shift	3D
Drive Off	Shift + Options
Factory	D. Menu
2nd Factory	Text
Set Up/Auto	Options
ID No. SET -	Shift + TV/R
Clear +	Shift + Exit
Power Control	Shift + Power
AV Selection	List
Power Off	Shift + Media
Power On	Shift + Smart

Original	Substituto
Zoom/Point	Eject
Zoom-	Shift + Ch -
Zoom+	Shift + Ch +
Freeze	Pause
Size/Screen	Format
Input 1	Shift + 1
Input 2	Shift + 2
Input 3	Shift + 3
Input 4	Shift + 4
Input 5	Shift + 5
Input 6	Shift + 6
Input 7	Shift + 7
Input 8	Shift + 8







Original	Substituto	Original	Substituto
 Power On/Off	 Power	 I-II MTS	 Dual
 Display	 Info	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 Integrator	 Smart
 3	 3	 Home	 Menu
 4	 4	 Exit	 Exit
 5	 5	 Return	 Back
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Enter/Set	 Ok
 CH Enter	 Pre Ch	 Red	 Red
 .	 Guide	 Green	 Green
 P/CH+	 Ch +	 Yellow	 Yellow
 P/CH-	 Ch -	 Blue	 Blue
 Muting	 Mute	 PC	 Media





Original	Substituto
Input	AV
Ext Input	Shift + AV
TV	TV/R
Split	Shift + 3D
Sub Input	Subt
Swap	Sleep
(PIP) Shift	3D
Drive Off	Shift + Options
Factory	D. Menu
2nd Factory	Text
Set Up/Auto	Options
ID No.Set -	Shift + TV/R
Clear +	Shift + Exit
Control Power	Shift + Power
AV Selection	List
Power Off	Shift + Media
Power On	Shift + Smart

Original	Substituto
Zoom-	Shift + Ch -
Zoom/Point	Eject
Zoom+	Shift + Ch +
Freeze	Pause
Size/Screen	Format
Input 1	Shift + 1
Input 2	Shift + 2
Input 3	Shift + 3
Input 4	Shift + 4
Input 5	Shift + 5
Input 6	Shift + 6
Input 7	Shift + 7
Input 8	Shift + 8

