






































































































Original	Substituto	Original	Substituto
 Power	 Power	 P+	 Ch +
 Source	 AV	 P-	 Ch -
 1	 1	 Home	 Smart
 2	 2	 G	 Guide
 3	 3	 i	 Info
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 Lang	 Dual	 Netflix	 Media
 TXT	 Text	 YouTube	 Shift + Media
 Vol+	 Vol +	 *1	 Format
 Vol-	 Vol -	 *2	 3D
 Mute	 Mute	 Red	 Red

Original	Substituto	Original	Substituto
 P+	 Ch +	 TV	 MUTE
 P-	 Ch -	 DVD	 SHIFT
 Home	 Smart	 SAT	 AUX
 G	 Guide	 PLAY MODE	 REC MODE
 i	 Info	 TV	 II
 Back	 Back	 ■	 ●
 Exit	 Exit	 ◀	 ▶
 Up	 Up	 DISC NAV	 SOUND
 Down	 Down	 AD	 SETTINGS
 Right	 Right	 LIST	 DUAL
 Left	 Left	 SUBT	 OPT
 OK	 Ok	 PROG	 PICTURE
 Netflix	 Media	 ECO	 3D
 YouTube	 Shift + Media	 SLEEP	 TV/R
 *1	 Format	 FORMAT	 TIMER
 *2	 3D	 E-MANUAL	 REPEAT
 Red	 Red	 ZOOM	 TEXT



