



















| Original | | Substituto | | Original | | Substituto | |
|----------|---------|------------|------------------|----------|-------------------|------------|-----------------------|
| | Power | | Power | | 7 | | 7 |
| | Mute | | Mute / Dimmer | | 8 | | 8 |
| | Vol- | | Vol- | | 9 | | 9 |
| | Vol+ | | Vol+ | | 0 | | 0 |
| | P- | | CH- / Page- | | -/-- | | Guide / EPG / -/-- |
| | P+ | | CH+ / Page+ | | Contrast- | | I<< / Preset- |
| | Power 2 | | Shift + Power | | Contrast+ | | >>I / Preset+ |
| | [+] | | Display / Media | | Brightness- | | Down |
| | PP | | Back / Return | | Brightness+ | | Up |
| | [] | | Info / Angle | | Text | | Text / Goto |
| | []↔ | | Picture / Format | | Text Subcode | | Subtitle / EQ |
| | 1 | | 1 | | Text Hold | | Shift + Stop / |
| | 2 | | 2 | | Text Size | | Zoom / Size |
| | 3 | | 3 | | Text Reveal | | Smart / List |
| | 4 | | 4 | | Text Index / Play | | Play / Slow |
| | 5 | | 5 | | Text Mix | | Shift + Text / |
| | 6 | | 6 | | Text Cancel | | Exit / Cancel / Clear |





































































| | Original | Substituto | Original | Substituto |
|---|--------------|---|----------|------------|
|  | Red / Rec |  Red / Netflix / Search | | |
|  | Red / Rec |  Rec / Rec Mode | | |
|  | Green / Stop |  Green / APP / Repeat | | |
|  | Green / Stop |  Stop / Hold | | |
|  | Yellow / << |  Yellow / YouTube / Repeat | | |
|  | Yellow / << |  << / Tune- | | |
|  | Blue / >> |  Blue / Prime Video / Random | | |
|  | Blue / >> |  >> / Tune+ | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |





| Original | | Substituto | | Original | | Substituto | |
|---|---------|---|------------------|---|--------------|---|-----------------------|
|  | Power |  | Power |  | 7 |  | 7 |
|  | Mute |  | Mute / Dimmer |  | 8 |  | 8 |
|  | Vol- |  | Vol- |  | 9 |  | 9 |
|  | Vol+ |  | Vol+ |  | 0 |  | 0 |
|  | P- |  | CH- / Page- |  | -/-- |  | Guide / EPG / -/-- |
|  | P+ |  | CH+ / Page+ |  | Text |  | Text / Goto |
|  | Power 2 |  | Shift + Power |  | Text Subcode |  | Subtitle / EQ |
|  | [+] |  | Display / Media |  | Text Hold |  | Shift + Stop / |
|  | PP |  | Back / Return |  | Text Size |  | Zoom / Size |
|  | [] |  | Info / Angle |  | Text Reveal |  | Smart / List |
|  | []↔ |  | Picture / Format |  | Play |  | Play / Slow |
|  | 1 |  | 1 |  | Text Mix |  | Shift + Text / |
|  | 2 |  | 2 |  | Text Cancel |  | Exit / Cancel / Clear |
|  | 3 |  | 3 |  | Rec |  | Rec / Rec Mode |
|  | 4 |  | 4 |  | Stop |  | Stop / Hold |
|  | 5 |  | 5 |  | << |  | << / Tune- |
|  | 6 |  | 6 |  | >> |  | >> / Tune+ |

