










































Original	Substituto	Original	Substituto
PWR	Power	Green	Green / APP / Repeat
TV/Rad	TV/Radio /	A/V+	AV / Input / RDS
TV/STB	Display / Media	Yellow / FAV	Yellow / YouTube / Repeat
1	1	FAV	Fav / Marker / PC
2	2	Blue / A-Z	Blue / Prime Video / Random
3	3	Blue / A-Z	Shift + Blue / Prime
4	4	Menu	Menu / Home
5	5	EPG	Guide / EPG / -/-
6	6	Info	Info / Angle
7	7	Up	Up
8	8	Left	Left
9	9	OK	OK
Back	Back / Return	Right	Right
0	0	Down	Down
Mute	Mute / Dimmer	Vol+	Vol+
Red	Red / Netflix / Search	Exit	Exit / Cancel / Clear
OPT	Setup / OPT /	PR/CH+	CH+ / Page+

Original	Substituto	Original	Substituto
Green	Green / APP / Repeat	TV	DVD
A/V+	AV / Input / RDS	SAT	AUX
Yellow / FAV	Yellow / YouTube / Repeat	SLOW	STEP-FREEZE
FAV	Fav / Marker / PC	HOLD	REC MODE
Blue / A-Z	Blue / Prime Video / Random	TUNE-	TUNE+
Blue / A-Z	Shift + Blue / Prime	PRESET-	PRESET+
Menu	Menu / Home	TITLE	LANG UII
EPG	Guide / EPG / -/-	EQ	SURROUND
Info	Info / Angle	SOUND	AUDIO
Up	Up	SUBTITLE	TIMER
Left	Left	PICTURE	ZOOM
OK	OK	SLEEP	PROGRAM
Right	Right	TOP MENU	OPT-TOOLS
Down	Down	GOTO	RDS
Vol+	Vol+	D.MENU	SETUP
Exit	Exit / Cancel / Clear	TEXT	AV INPUT
PR/CH+	CH+ / Page+	HOME	ANGLE





Original	Substituto	
PWR On/Off		Power
East		D.Menu / Top
TV	 +  Shift + 1	
Dec/Pause		Pause / Step / Freeze
Alt/16:9		Picture / Format
H/V Play		Play / Slow
Opt?		Setup / OPT /
FAV Pref.		Fav / Marker / PC
4ghi		4
Guide Pilote	 +  Shift + Guide / EPG / -/-	
9wxyz		9
8tuv		8
7pqrm		7
6mno		6
3def		3
5jkl		5
2abc		2

Original	Substituto	
1. ?		1
Yellow		Yellow / YouTube / Repeat
LNB F.Forward		>> / Tune+
Lang./Rewind		<< / Tune-
TV/SAT		AV / Input / RDS
West		>>I / Preset+
Dev		I<<< / Preset-
0/10		0
Video	 +  Shift + 4	
Red		Red / Netflix / Search
Green		Green / APP / Repeat
Blue		Blue / Prime Video / Random
Freeze	 +  Shift + Pause / Step /	
Menu Up		Up
Mute		Mute / Dimmer
Epg		Guide / EPG / -/-
App	 +  Shift + Green / APP / Repeat	





Original	Substituto	
Info		Info / Angle
Subt.List		Subtitle / EQ
Sleep Timer		Sleep / Timer
Text		Text / Goto
Zoom		Zoom / Size
Menu		Menu / Home
Display		Display / Media
Menu Left		Left
OK Enter		OK
Menu Right		Right
Exit		Exit / Cancel / Clear
Menu Down		Down
Back		Back / Return
Volume+		Vol+
CH/Page+		CH+ / Page+
Volume-		Vol-
Audio		Audio / Lang I/II

Original	Substituto	
CH/Page-		CH- / Page-

