



















































































Original	Substituto	Original	Substituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
App	 Media	Menu Down	 Down
Opt?	 Options	Audio	 Dual
TV	 TV/R	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7







































Original	Substituto	Original	Substituto
8tuv	 8	+	 +  Shift + Subt
9wxyz	 9	Auth./DISEQC	 +  Shift + Smart
Guide Pilote	 GUIDE	Sys/Serv	 +  Shift + Sleep
0/10	 0	Home Cinema	 Smart
FAV Pref.	 PRE-CH	Scan/Setup	 +  Shift + Options
Red	 A	Interat	 +  Shift + D. Menu
Green	 B	Pers.	 +  Shift + Eject
Yellow	 C	Tune-	 +  Shift + Left
Freeze	 Freeze	East	 >>I
Blue	 D	H/V Play	 Play
Dev	 LIST	LNB F.Forward	 >>
22Khz	 3D	Lang./Rewind	 <<
West	 I<<	Alt/16:9	 Format
Radio	 +  Shift + TV/R	Aft/Caf	 +  Shift + Ok
On/Off	 +  Shift + Power	Tune+	 +  Shift + Right
Dec/Pause	 Pause		 +  Shift + Exit
	 +  Shift + Mute	Browse	 +  Shift + Back



Original	Substituto	Original	Substituto
	SHIFT + CH + Shift + Ch +		
	SHIFT + CH - Shift + Ch -		
View	SHIFT + 0 Shift + 0		






































Original	Substituto	Original	Substituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7











Original	Substituto	Original	Substituto
8tuv	 8	SAT Sky	 +  Shift + AV
9wxyz	 9	Navi Mode	 +  Shift + Menu
Guide Pilote	 Guide	Browse	 +  Shift + Media
0/10	 0	Search	 +  Shift + Up
FAV Pref.	 Pre Ch	Auth./DISEQC	 3D
Red	 Red	Tune-	 +  Shift + Left
Green	 Green	Tune+	 +  Shift + Right
Yellow	 Yellow	East	 >>
Blue	 Blue		 +  Shift + Exit
On/Off	 +  Shift + Power	Lang./Rewind	 <<
Scan/Setup	 +  Shift + Options	H/V Play	 Play
Radio	 +  Shift + TV/R	Store	 +  Shift + Down
	 +  Shift + Mute	Alt/16:9	 Format
22Khz	 List		 +  Shift + Vol +
+	 +  Shift + Subt	Home Cinema	 Smart
Sys/Serv	 +  Shift + Sleep		 +  Shift + Vol -
Pers.	 +  Shift + Eject		







































Original	Substituto	Original	Substituto
PWR On/Off	 Power	Exit	 Exit
Mute	 Mute	Menu Down	 Down
Opt?	 Options	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Audio	 Dual
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8
Menu Right	 Right	9wxyz	 9



Original	Substituto	Original	Substituto
Guide Pilote		Guide	
0/10		0	
FAV Pref.		Pre Ch	
Red		Red	
Green		Green	
Dec/Pause		Pause	
Lang./Rewind		<<	
Freeze		Stop	
LNB F.Forward		>>	
H/V Play		Play	
East		>>	
Yellow		Yellow	
Blue		Blue	



Original	Substituto	Original	Substituto
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7



Original	Substituto	
8tuv		8
9wxyz		9
Guide Pilote		Guide
0/10		0
FAV Pref.		Pre Ch
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue
On/Off	 + 	Shift + Power
Scan/Setup	 + 	Shift + Options
	 + 	Shift + Mute
Dec/Pause		Pause
+	 + 	Shift + Subt
Sys/Serv	 + 	Shift + Sleep
Interat	 + 	Shift + D. Menu
SAT Sky	 + 	Shift + AV

Original	Substituto	
22Khz		List
Radio	 + 	Shift + TV/R
Navi Mode	 + 	Shift + Menu
Search	 + 	Shift + Up
Tune-	 + 	Shift + Left
Tune+	 + 	Shift + Right
	 + 	Shift + Exit
Store	 + 	Shift + Down
	 + 	Shift + Vol +
	 + 	Shift + Ch +
	 + 	Shift + Vol -
Home Cinema		Smart
	 + 	Shift + Ch -
De-emph	 + 	Shift + 1
Swap	 + 	Shift + 2
P.lock	 + 	Shift + 3
Wn	 + 	Shift + 4



Original	Substituto	Original	Substituto
50j17	 +  Shift + 5		
Auth./DISEQC	 3D		
Help	 +  Shift + 6		
Copy/Delete	 +  Shift + 7		
Erase	 +  Shift + 8		
View	 +  Shift + 0		
Alt/16:9	 Format		

