











































































Original	Substituto	Original	Substituto
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Blue	 Blue
 Pause	 Pause	 CH+	 Ch +
 <<<	 <<<	 CH-	 Ch -
 >>>	 >>>	 Source	 AV
 <<<	 <<<	 Vol+	 Vol +
 >>>	 >>>	 Vol-	 Vol -
 Stop	 Stop	 Menu	 Menu
 TV/TXT	 Text	 Rec	 Rec
 Cancel	 Eject	 Up	 Up
 Reveal	 D. Menu	 Down	 Down
 Hold	 Media	 Right	 Right
 Size	 3D	 Left	 Left
 Subpage	 Shift + Subt	 OK	 Ok
 Index	 List	 DVB	 Smart
 Red	 Red	 Exit	 Exit
 Green	 Green	 1	 1





Original	Substituto
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Substituto
	
	
	
	
	
	
	
	
	

