










































































| Original   | Substituto  | Original  | Substituto   |
|--|---|---|--|
|  Power    |  Power                       |  PR+       |  CH+ / Page+              |
|  TV       |  Display / Media             |  PR-       |  CH- / Page-              |
|  1        |  1                           |  Source    |  AV / Input / RDS         |
|  2        |  2                           |  Info      |  Info / Angle             |
|  3        |  3                           |  Menu      |  Menu / Home              |
|  4        |  4                           |  Guide     |  Guide / EPG / -/--       |
|  5        |  5                           |  Tools     |  Setup / OPT /            |
|  6        |  6                           |  Return    |  Back / Return            |
|  7        |  7                           |  Up        |  Up                       |
|  8        |  8                           |  Down      |  Down                     |
|  9       |  9                          |  Right    |  Right                   |
|  0      |  0                         |  Left    |  Left                   |
|  PRE-CH |  Shift + Fav / Marker / PC |  Enter   |  OK                     |
|  Vol+   |  Vol+                      |  CH List |  Smart / List           |
|  FAV.CH |  Fav / Marker / PC         |  Exit    |  Exit / Cancel / Clear  |
|  Vol-   |  Vol-                      |  Red     |  Red / Netflix / Search |
|  Mute   |  Mute / Dimmer             |  Green   |  Green / APP / Repeat   |

| Original   | Substituto  | Original  | Substituto   |
|--|---|---|--|
|  Power        |  MUTE          |  SHIFT           |  |
|  TV           |  DVD           |  SAT             |  AUX      |
|  SLOW         |  STEP-FREEZE   |  HOLD            |  REC MODE |
|  TUNE-        |  TUNE+         |  PRESET-         |  PRESET+  |
|  TITLE        |  LANG UI       |  EQ              |  SURROUND |
|  SOUND        |  AUDIO         |  SUBTITLE        |  PROGRAM  |
|  FORMAT       |  SIZE          |  TIMER           |  TV RADIO |
|  PICTURE      |  ZOOM          |  SLEEP           |  RDS      |
|  TOP MENU     |  OPT-TOOLS     |  GOTO            |  AV INPUT |
|  D.MENU       |  SETUP         |  TEXT            |  HOME     |
|  HOME         |  ANGLE         |  MENU            |  INFO     |
|  CLEAR        |  EXIT          |  CANCEL          |  RETURN   |
|  LIST        |  SMART        |  MEDIA          |  CH PAGE |
|  TV         |  DVD         |  CD - STB      |  VOL+   |
|  VIDEO      |  TAPE        |  TUNER         |  VOL-   |
|  AUX - HDD  |  USB         |  BLUETOOTH     |  1      |
|  HDMI - BAT |  PC          |  FAV MARKER    |  2      |
|  GUIDE EPG  |  NETFLIX     |  APP           |  3      |
|  SEARCH     |  REPEAT      |  REPEAT A-B    |  4      |
|  RANDOM     |  Mandis SHOP |  www.mandis.tv |  5      |
|  |  6           |  7             |  8      |
|  |  9           |  0             |  10     |



