



Original	Substituto	Original	Substituto
	Power		Power
	Screen		Picture / Format
	Lang		Audi o / Lang I / II
	Subt itle		Subt itle / EQ
	Wor ld		Smart / Li st
	Red/ ↑		Red / Netfl ix / Search
	Green/ ↓		Green / APP / Repeat
	Yel low		Yel low / You Tube / Repeat
	Bl ue		Bl ue / Pri me Video / Random
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	[≡]		Text / Got o
	9		9
	0		0
	Recal l		Back / Ret urn
	Up		Up
	Menu		Menu / Home
	Ri ght		Ri ght
	Lef t		Lef t
	Ret urn		Shi ft + Back / Ret urn
	Ret urn		Exi t / Cancel / Cl ear
	Down		Down
	OK		OK
	Source		AV / I nput / RDS
	FAV		Fav / Marker / PC
	Presets		Di spl ay / Medi a
	Sl eep		Sl eep / Ti mer
	Vol +		Vol +



