





































Original	Substituto
Open/Close	Eject / Surround
Power	Power
VCR	Shift + 4
DVD	Shift + 2
Input	AV / Input / RDS
1/Tracking-	1
2	2
3/Tracking+	3
4	4
5	5
6	6
7	7
8	8
9	9
System	Smart / List
0	0
Clear	Exit / Cancel / Clear

Original	Substituto
Setup	Setup / OPT /
Up	Up
PR+	CH+ / Page+
Display	Display / Media
Left	Left
OK/Enter	OK
Right	Right
Title/PBC	Sound / Title
PR-	CH- / Page-
Down	Down
Menu	Menu / Home
Subtitle	Subtitle / EQ
Audio	Audio / Lang I/II
Search	Red / Netflix / Search
Zoom	Zoom / Size
<<	<< / Tune-
Pause	Pause / Step / Freeze
































Original	Substituto
 Open/Close	 Eject / Surround
 Power	 Power
 VCR	 Shift + 4
 DVD	 Shift + 2
 Input	 AV / Input / RDS
 1/Tracking-	 1
 2	 2
 3/Tracking+	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 System	 Smart / List
 0	 0
 Clear	 Exit / Cancel / Clear

Original	Substituto
 Setup	 Setup / OPT /
 Up/PR+	 Up
 Up/PR+	 CH+ / Page+
 Display	 Display / Media
 Left	 Left
 OK/Enter	 OK
 Right	 Right
 Title/PBC	 Sound / Title
 Down/PR-	 CH- / Page-
 Down/PR-	 Down
 Menu	 Menu / Home
 Subtitle	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Search	 Red / Netflix / Search
 Zoom	 Zoom / Size
 <<	 << / Tune-
 Play	 Play / Slow





Original		Substituto		Original	Substituto
	Pause		Pause / Step / Freeze		
	>>		>> / Tune+		
	I<<		I<< / Preset-		
	Stop		Stop / Hold		
	>>I		>>I / Preset+		
	Rec		Rec / Rec Mode		
	Speed		Picture / Format		
	Repeat		Green / APP / Repeat		
	A-B		Yellow / YouTube / Repeat		
	Tv/VCR		TV/Radio /		
	3D	 + 	Shift + 3		
	Mark		Fav / Marker / PC		
	Angle		Info / Angle		
	CM Skip		Guide / EPG / --		
	Replay		Text / Goto		
	Last CH		Back / Return		
	Program	 + 	Shift + TV/Radio / Program		

