



















































































Original	Substituto
 Power Tv	 Power
 NET	 Media
 [i+]	 Info
 FAV	 Shift + Pre Ch
 ATV	 Smart
 DTV	 D. Menu
 SAT	 Shift + Media
 Radio	 TV/R
 Power Source	 Shift + Power
 << Source	 Shift + <<
 Play Source	 Play
 >> Source	 Shift + >>
 USB Rec	 Shift + Rec
 Rec Source	 Rec
 Rec Stop	 Shift + Stop
 Stop Source	 Stop
 Ready/Time Shift	 Options

Original	Substituto
 ←	 Shift + Left
 →	 Shift + Right
 Pause	 Pause
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 Source	 AV
 I/II/I+II/▼/0	 Dual
 [<>]	 Format



T



	Original	Substituto	Original	Substituto
	AV Mode	 Shift + AV		Ok
	Eco	 Shift + 3D		>>
	Vol+	 Vol +		<<
	Vol-	 Vol -		>>
	Mute	 Mute		<<
	P+	 Ch +		[...]
	P-	 Ch -		[≡?]
	[≡]	 Text		List
	3D	 3D		Sleep
	End	 Exit		Eject
	EPG	 Guide		Red
	Back	 Back		Green
	Menu	 Menu		Yellow
	Up	 Up		Blue
	Down	 Down		
	Right	 Right		
	Left	 Left		

