





































Original	Substituto	Original	Substituto
 ON/OFF	On/Off	 Power	Power
 Freeview Play	Freeview Play	 Options	Options
 1	1	 1	1
 2	2	 2	2
 3	3	 3	3
 4	4	 4	4
 5	5	 5	5
 6	6	 6	6
 7	7	 7	7
 8	8	 8	8
 9	9	 9	9
 0	0	 0	0
 Tv Guide	Tv Guide	 Guide	Guide
 Picture	Picture	 Format	Format
 Sound	Sound	 Dual	Dual
 Source	Source	 AV	AV
 Vol+	Vol+	 Vol +	Vol +

Original	Substituto	Original	Substituto
 Vol-	Vol-	 Vol -	Vol -
 Mute	Mute	 Mute	Mute
 CH+	CH+	 Ch +	Ch +
 CH-	CH-	 Ch -	Ch -
 Menu	Menu	 Menu	Menu
 Exit	Exit	 Exit	Exit
 Back	Back	 Back	Back
 FAV	FAV	 Pre Ch	Pre Ch
 Up	Up	 Up	Up
 Down	Down	 Down	Down
 Right	Right	 Right	Right
 Left	Left	 Left	Left
 OK	OK	 Ok	Ok
 Info	Info	 Info	Info
 Text	Text	 Text	Text
 Subtitle	Subtitle	 Subt	Subt
 TV	TV	 TV/R	TV/R





Original	Substituto
You Tube	Media
Netflix	Smart
APPs	Shift + Media
Rec/DVD Menu	Rec
I<<	I<<
>>I	>>I
Stop	Stop
Rec List/DVD	D. Menu
<<	<<
>>	>>
Play	Play
Pause	Pause
Red/Goto	Red
Green/A-B	Green
Yellow/Angle	Yellow
Blue/Repeat	Blue

Original	Substituto

