

































Original	Substituto
	 Power
	 Mute / Dimmer
	 [] Display / Media
	 [=] Text / Goto
	 Input AV / Input / RDS
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 -/-- Guide / EPG / -/--
	 [i+] Info / Angle

Original	Substituto
	 Menu / Home
	 [+] Picture / Format
	 Up
	 Green / APP / Repeat
	 Blue / Prime Video / Random
	 Down
	 Right
	 Yellow / YouTube / Repeat
	 Left
	 Red / Netflix / Search
	 Vol+
	 Vol-
	 PR+ CH+ / Page+
	 PR- CH- / Page-

