




Original	Substituto	Original	Substituto
	Power		Red / Netflix / Search
	1		Green / APP / Repeat
	2		Yellow / YouTube / Repeat
	3		Blue / Prime Video / Random
	4		Guide / EPG / -/-
	5		Smart / List
	6		AV / Input / RDS
	7		Menu / Home
	8		Display / Media
	9		Up
	0		Down
	Info / Angle		Right
	Text / Goto		Left
	Shift + Yellow / YouTube /		OK
	Shift + Red / Netflix /		Back / Return
	Shift + Green / APP /		TV/Radio /
	Shift + Blue / Prime Video / Random		Shift + Menu / Home





	Original	Substituto	Original	Substituto
		Vol+		Vol+
		Vol-		Vol-
		Mute		Mute / Dimmer
		Recall		Fav / Marker / PC
		CH+		CH+ / Page+
		CH-		CH- / Page-
		Audio		Audio / Lang I/II
		[...]		Subtitle / EQ
		Help		Zoom / Size
		<<		<< / Tune-
		Play		Play / Slow
		>>		>> / Tune+
		Rec		Rec / Rec Mode
		Pause		Pause / Step / Freeze
		Exit		Exit / Cancel / Clear

