







































































Original	Substituto	Original	Substituto
 Power	 Power	 -/--	 Guide / EPG / -/--
 SET	 Fav / Marker / PC	 Prog+	 CH+ / Page+
 Wide	 Zoom / Size	 Prog-	 CH- / Page-
 Hi-Speed REW	 Shift + << /	 Vol+	 Vol+
 Counter Remain	 Red / Netflix / Search	 Vol-	 Vol-
 TV/Video	 TV/Radio /	 Play	 Play / Slow
 Eject	 Eject / Surround	 Stop	 Stop / Hold
 1	 1	 Pause	 Pause / Step / Freeze
 2	 2	 FF	 >> / Tune+
 3	 3	 Index Search >>I	 >>I / Preset+
 4	 4	 I<< Index Search	 I<< / Preset-
 5	 5	 REW	 << / Tune-
 6	 6	 Skip	 Exit / Cancel / Clear
 7	 7	 Wheel >	 Shift + >>I / Preset+
 8	 8	 Up	 Up
 9	 9	 < Wheel	 Shift + I<< / Preset-
 0	 0	 Down	 Down





Original	Substituto	Original	Substituto
	Power		Power
	Wide		Zoom / Size
	Display		Display / Media
	TV/Video		TV/Radio /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide / EPG / -/--
	Vol+		Vol+
	Vol-		Vol-
	Prog+		CH+ / Page+
	Prog-		CH- / Page-
	Audio Monitor		Audio / Lang I/II
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	[≡]		Text / Goto
	□		Smart / List

