



| Original  | Substituto |
|---|------------|
|    | Power      |
|    | Mute       |
|    | 1          |
|    | 2          |
|    | 3          |
|    | 4          |
|    | 5          |
|    | 6          |
|    | 7          |
|    | 8          |
|  | 9          |
|  | 0          |
|  | DTV/ATV    |
|  | Recall     |
|  | P.Mode     |
|  | S.Mode     |
|  | Sleep      |

| Original  | Substituto |
|---|------------|
|    | Menu       |
|    | Source     |
|    | Up         |
|    | Left       |
|    | Enter      |
|    | Right      |
|    | Down       |
|    | Exit       |
|    | Display    |
|    | Vol+       |
|  | Vol-       |
|  | MTS        |
|  | Rec List   |
|  | CH+        |
|  | CH-        |
|  | FAV/List   |
|  | Rec        |










































| Original               | Substituto                    |
|------------------------|-------------------------------|
| Freeze                 | Pause / Step / Freeze         |
| Guide                  | Guide / EPG / -/-             |
| <<                     | << / Tune-                    |
| >> / Aspect            | >> / Tune+                    |
| >> / Aspect            | Shift + Picture / Format      |
| << / Cancel            | << / Preset-                  |
| << / Cancel            | Shift + Exit / Cancel / Clear |
| >>  / Sub.PG           | >>  / Preset+                 |
| Stop / Index           | Stop / Hold                   |
| Play/Pause / Timeshift | Play / Slow                   |
| Tv/Radio               | TV/Radio /                    |
| Subtitle               | Subtitle / EQ                 |
| Reveal                 | Eject / Surround              |
| Size                   | Zoom / Size                   |
| Hold                   | Shift + Stop /                |
| Text                   | Text / Goto                   |
| Red                    | Red / Netflix / Search        |

| Original | Substituto                  |
|----------|-----------------------------|
| Green    | Green / APP / Repeat        |
| Yellow   | Yellow / YouTube / Repeat   |
| Cyan     | Blue / Prime Video / Random |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |
|          |                             |





| Original  | Substituto | Original  | Substituto       |
|---|------------|---|------------------|
|    | Power      |    | Power            |
|    | Mute       |    | Mute / Dimmer    |
|    | 1          |    | 1                |
|    | 2          |    | 2                |
|    | 3          |    | 3                |
|    | 4          |    | 4                |
|    | 5          |    | 5                |
|    | 6          |    | 6                |
|    | 7          |    | 7                |
|   | 8          |   | 8                |
|  | 9          |  | 9                |
|  | 0          |  | 0                |
|  | DTV/ATV    |  | D.Menu / Top     |
|  | Recall     |  | Back / Return    |
|  | P.Mode     |  | Picture / Format |
|  | S.Mode     |  | Sound / Title    |
|  | Sleep      |  | Sleep / Timer    |

| Original  | Substituto | Original  | Substituto            |
|---|------------|---|-----------------------|
|    | Menu       |    | Menu / Home           |
|    | Source     |    | AV / Input / RDS      |
|    | Up         |    | Up                    |
|    | Left       |    | Left                  |
|    | Enter      |    | OK                    |
|    | Right      |    | Right                 |
|    | Down       |    | Down                  |
|    | Exit       |    | Exit / Cancel / Clear |
|    | Display    |    | Display / Media       |
|   | Vol+       |   | Vol+                  |
|  | Vol-       |  | Vol-                  |
|  | MTS        |  | Info / Angle          |
|  | Rec List   |  | Smart / List          |
|  | CH+        |  | CH+ / Page+           |
|  | CH-        |  | CH- / Page-           |
|  | FAV/List   |  | Fav / Marker / PC     |
|  | Rec        |  | Rec / Rec Mode        |





|   | Original               | Substituto  |   | Original | Substituto  |
|---|------------------------|---|---|----------|---|
|    | Freeze                 |  Pause / Step / Freeze         |  | Green    |  Green / APP / Repeat        |
|    | Guide                  |  Guide / EPG / -/-             |  | Yellow   |  Yellow / YouTube / Repeat   |
|    | <<                     |  << / Tune-                    |  | Cyan     |  Blue / Prime Video / Random |
|    | >> / Aspect            |  >> / Tune+                    |   |          |   |
|    | >> / Aspect            |  Shift + Picture / Format      |   |          |   |
|    | I<< / Cancel           |  I<< / Preset-                 |   |          |   |
|    | I<< / Cancel           |  Shift + Exit / Cancel / Clear |   |          |   |
|    | >>I / Sub.PG           |  >>I / Preset+                 |   |          |   |
|    | Stop / Index           |  Stop / Hold                   |   |          |   |
|    | Play/Pause / Timeshift |  Play / Slow                   |   |          |   |
|   | Tv/Radio               |  TV/Radio /                   |   |          |   |
|  | Subtitle               |  Subtitle / EQ               |   |          |   |
|  | Reveal                 |  Eject / Surround            |   |          |   |
|  | Size                   |  Zoom / Size                 |   |          |   |
|  | Hold                   |  Shift + Stop /              |   |          |   |
|  | Text                   |  Text / Goto                 |   |          |   |
|  | Red                    |  Red / Netflix / Search      |   |          |   |

