



























































































Original	Substituto	Original	Substituto
 Power	 Power	 Yellow	 Yellow
 Play	 Play	 Blue	 Blue
 Pause	 Pause	 CH+	 Ch +
 <<<	 <<<	 CH-	 Ch -
 >>>	 >>>	 Source	 AV
 I<<<	 I<<<	 Vol+	 Vol +
 >>I	 >>I	 Vol-	 Vol -
 Stop	 Stop	 Menu	 Menu
 TV/TXT	 Text	 Rec	 Rec
 Cancel	 Eject	 Up	 Up
 Reveal	 D. Menu	 Down	 Down
 Hold	 Media	 Right	 Right
 Size	 3D	 Left	 Left
 Subpage	 Shift + Subt	 OK	 Ok
 Index	 List	 DVB	 Smart
 Red	 Red	 Exit	 Exit
 Green	 Green	 1	 1





Original	Substituto	Original	Substituto
 2	2	 2	2
 3	3	 3	3
 4	4	 4	4
 5	5	 5	5
 6	6	 6	6
 7	7	 7	7
 8	8	 8	8
 9	9	 9	9
 0	0	 0	0
 -/--	-/--	 SHIFT + 	Shift + Guide
	Recall		Back
	Picture	 SHIFT + 	Shift + Format
	Sound	 SHIFT + 	Shift + Dual
	Nicam/A2		Options
	Mute		Mute
	Sleep		Sleep
	Tv/Radio		TV/R

Original	Substituto	Original	Substituto
	FAV		Pre Ch
	FAV+	 SHIFT + 	Shift + Ch +
	FAV-	 SHIFT + 	Shift + Ch -
	Subtitle		Subt
	Pic Format		Format
	Text	 SHIFT + 	Shift + Text
	Display		Info
	Language		Dual
	EPG		Guide

