































| Original | Substituto | Original | Substituto |
|---|------------|--|---------------|
|  | Power |  | Power |
|  | Mute |  | Mute |
|  | TV |  | Media |
|  | Text |  | Text |
|  | Info |  | Info |
|  | PIP |  | Smart |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | -/-- |  +  +  | Shift + Guide |

| Original | Substituto | Original | Substituto |
|---|------------|---|--------------|
|  | Source |  | AV |
|  | Menu |  | Menu |
|  | DTV Guide |  +  | Guide |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Enter |  | Ok |
|  | PR+ |  | Ch + |
|  | PR- |  | Ch - |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Exit |  | Exit |
|  | ARC |  | 3D |
|  | Recall |  | Back |
|  | Mix |  +  | Shift + Text |
|  | Subpage |  | Subt |





| Original | Substituto |
|---|---|
|  |  Options |
|  |  Eject |
|  |  Shift + Options |
|  |  Play |
|  |  Shift + Info |
|  |  Red |
|  |  Green |
|  |  Yellow |
|  |  Pause |
|  |  Blue |
|  |  >> |
|  |  Sleep |
|  |  << |
|  |  I<< |
|  |  D. Menu |
|  |  TV/R |
|  |  >>I |

| Original | Substituto |
|---|---|
|  |  Shift + Media |
|  |  Dual |
|  |  Shift + Power |
|  |  Shift + Subt |
|  |  Shift + Dual |
|  |  List |
|  |  Format |
|  |  Pre Ch |
|  |  Shift + Red |
|  |  Shift + Yellow |
|  |  Shift + Green |
|  |  Shift + Back |

