



| Original | | Substituto | | Original | | Substituto | |
|----------|--------|------------|-------|----------|---------|------------|----------------|
| | Power | | Power | | EPG | + | Shift + Guide |
| | Mute | | Mute | | Up | | Up |
| | 1 | | 1 | | Down | | Down |
| | 2 | | 2 | | Right | | Right |
| | 3 | | 3 | | Left | | Left |
| | 4 | | 4 | | Enter | | Ok |
| | 5 | | 5 | | CH+ | | Ch + |
| | 6 | | 6 | | CH- | | Ch - |
| | 7 | | 7 | | FAV+ | + | Shift + Ch + |
| | 8 | | 8 | | FAV- | + | Shift + Ch - |
| | 9 | | 9 | | Vol+ | | Vol + |
| | 0 | | 0 | | Vol- | | Vol - |
| | -/-- | | Guide | | Sleep | | Sleep |
| | Recall | | Back | | P.Mode | + | Shift + Format |
| | Menu | | Menu | | S.Mode | + | Shift + Dual |
| | Exit | | Exit | | FAV | | Pre Ch |
| | Tv/AV | | AV | | Display | | Info |





| Original | Substituto | Original | Substituto |
|---|---|--|--|
|  P.Size |  Format |  Green |  Green |
|  Nicam/A2 |  Options |  Yellow |  Yellow |
|  Tv/Radio |  TV/R |  Cyan |  Blue |
|  Text |  Text | | |
|  Index |  Smart | | |
|  Subtitle |  Subt | | |
|  I<</Hold |  I<< | | |
|  Audio |  Dual | | |
|  >>I/Size |  >>I | | |
|  <</Subpage |  << | | |
|  >>/Reveal |  >> | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
|  Stop |  Stop | | |
|  Rec/PVR |  Rec | | |
|  Media |  Media | | |
|  Red |  Red | | |

