



| Original | | Substituto | | Original | | Substituto | |
|----------|--------|------------|-----------------------------|----------|------------|------------|-----------------------|
| | Power | | Power | | TV | | Shift + 1 |
| | 1 | | 1 | | Up / P+ | | Shift + Up |
| | 2 | | 2 | | Up / P+ | | Up |
| | 3 | | 3 | | AV | | AV / Input / RDS |
| | 4 | | 4 | | Left / V- | | Left |
| | 5 | | 5 | | Left / V- | | Shift + Left |
| | 6 | | 6 | | Menu | | Menu / Home |
| | 7 | | 7 | | Menu | | Shift + Menu / |
| | 8 | | 8 | | Right / V+ | | Right |
| | 9 | | 9 | | Right / V+ | | Shift + Right |
| | Mute | | Mute / Dimmer | | S / M / D | | Exit / Cancel / Clear |
| | 0 | | 0 | | Down / P- | | Shift + Down |
| | 16:9 | | Picture / Format | | Down / P- | | Down |
| | Red | | Red / Netflix / Search | | Recall | | Back / Return |
| | Green | | Green / APP / Repeat | | Recall | | Shift + Back / Return |
| | Yellow | | Yellow / YouTube / Repeat | | i | | Info / Angle |
| | Blue | | Blue / Prime Video / Random | | EQ | | Subtitle / EQ |





| Original | Substituto |
|----------|----------------------|
| | Shift + Info / Angle |
| | Sound / Title |
| | Text / Goto |
| | Setup / OPT / |
| | Stop / Hold |
| | Zoom / Size |
| | Sleep / Timer |
| | D.Menu / Top |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Substituto |
|----------|------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

