




































































Original	Substituto	Original	Substituto
 Power	 Power	 Blue	 Blue / Prime Video / Random
 Input	 AV / Input / RDS	 [=]	 D.Menu / Top
 1	 1	 Up	 Up
 2	 2	 Play	 Play / Slow
 3	 3	 Pause	 Pause / Step / Freeze
 4	 4	 Left	 Left
 5	 5	 OK	 OK
 6	 6	 Right	 Right
 7	 7	 Back	 Back / Return
 8	 8	 Down	 Down
 9	 9	 Exit	 Exit / Cancel / Clear
 Guide	 Guide / EPG / -/--	 Vol+	 Vol+
 0	 0	 Home	 Menu / Home
 CH.List	 Smart / List	 CH+ / Page+	 CH+ / Page+
 Red	 Red / Netflix / Search	 Vol-	 Vol-
 Green	 Green / APP / Repeat	 Mute	 Mute / Dimmer
 Yellow	 Yellow / YouTube / Repeat	 CH- / Page-	 CH- / Page-



