








































































































Original	Substituto	Original	Substituto
 Power	 Power	 Info	 Info
 3D	 3D	 P +	 Ch +
 1	 1	 P -	 Ch -
 2	 2	 W	 Shift + Smart
 3	 3	 Smart TV	 Smart
 4	 4	 @	 Media
 5	 5	 Menu	 Menu
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right / Zoom +	 Right
 9	 9	 Left / Zoom -	 Left
 0	 0	 OK	 Ok
 ECO	 Shift + 3D	 Back	 Back
 Source	 AV	 Exit	 Exit
 Vol +	 Vol +	 Option	 Options
 Vol -	 Vol -	 USB	 Shift + Media
 Mute	 Mute	 TV	 TV/R





Original	Substituto	Original	Substituto
 SLEEP	Sleep	 SLEEP	Sleep
 GUIDE	Guide	 GUIDE	Guide
 FAV	FAV	 PRE-CH	Pre Ch
 LIST	List	 LIST	List
 Red	Red	 A	Red
 Green	Green	 B	Green
 Yellow	Yellow	 C	Yellow
 Blue	Blue	 D	Blue
 LANG	Lang	 DUAL	Dual
 SUBTITLE	Subtitle	 SUBT	Subt
 TEXT	Text	 TEXT	Text
 I<	I<	 I<<	I<<
 Stop	Stop	 Stop	Stop
 Play / Pause	Play / Pause	 PLAY MODE	Play
 Play / Pause	Play / Pause	 II	Pause
 >I	>I	 >>I	>>I
 <<	<<	 <<	<<
		 Rec	Rec
		 REC MODE	Rec
		 >>	>>
		 >>>	>>>

