



Original	Substituto
Source / Eject	Shift + AV / Input / RDS
Power	Power
List	Smart / List
TV	Shift + 1
BD/DVD/VOD	Shift + 2
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
AV	AV / Input / RDS
0 / --	0
FAV	Fav / Marker / PC

Original	Substituto
Exit	Exit / Cancel / Clear
Menu	Menu / Home
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Guide	Guide / EPG / -/-
Return	Back / Return
Info	Info / Angle
Vol +	Vol+
ECO	TV/Radio /
PR +	CH+ / Page+
Vol -	Vol-
Mute	Mute / Dimmer
PR -	CH- / Page-
Red / A-B	Red / Netflix / Search







Original	Substituto
 Source / Eject	 Shift + AV / Input / RDS
 Source / Eject	 Eject / Surround
 Power	 Power
 List	 Smart / List
 TV	 Shift + 1
 BD/DVD/VOD	 Shift + 2
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 AV	 AV / Input / RDS
 0 / --	 0

Original	Substituto
 FAV	 Fav / Marker / PC
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Guide	 Guide / EPG / -/-
 Return	 Back / Return
 Info	 Info / Angle
 Vol +	 Vol+
 ECO	 TV/Radio /
 PR +	 CH+ / Page+
 Vol -	 Vol-
 Mute	 Mute / Dimmer
 PR -	 CH- / Page-



