



| Original | Substituto | Original | Substituto |
|----------|-------------|----------|--------------------------------|
| | Power | | Power |
| | Micro | | Smart / List |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |
| | Back | | Back / Return |
| | Home | | Menu / Home |
| | ≡ | | Setup / OPT / |
| | << | | << / Tune- |
| | Play | | Play / Slow |
| | Pause | | Pause / Step / Freeze |
| | >> | | >> / Tune+ |
| | Vol+ | | Vol+ |
| | Guide | | Guide / EPG / -/- |
| | ▲ | | CH+ / Page+ |
| | Vol- | | Vol- |
| | Mute | | Mute / Dimmer |
| | ▼ | | CH- / Page- |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | Subt | | Subtitle / EQ |
| | 0 | | 0 |
| | TXT | | Text / Goto |
| | prime video | | Shift + Blue / Prime |
| | Netflix | | Shift + Red / Netflix / Search |



