


























































































Original	Substituto
 Power	 Power
 TV	 Smart / List
 Text	 Text / Goto
 Source 2	 Shift + AV / Input / RDS
 Source 1	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 Contrast-	 I<< / Preset-
 Contrast+	 >>I / Preset+
 4	 4
 5	 5
 6	 6
 Brightness-	 Down
 Brightness+	 Up
 7	 7
 8	 8

Original	Substituto
 9	 9
 Sol-	 << / Tune-
 Sol+	 >> / Tune+
 =<	 Shift + CH- /
 0	 0
 - / - / =>	 Shift + CH+ /
 - / - / =>	 Guide / EPG / - / -
 Fa-	 Left
 Fa+	 Right
 Vol-	 Vol-
 Vol+	 Vol+
 ><-	 CH- / Page-
 ><+	 CH+ / Page+
 OO	 Sound / Title
 I-II	 Audio / Lang I/II
 []	 Zoom / Size
 Mute	 Mute / Dimmer





Original	Substituto	Original	Substituto
	PP		Back / Return
	Exit		Exit / Cancel / Clear
	Size		Shift + Zoom / Zoom /
	Cancel		Shift + Exit / Cancel / Clear
	[+]		Info / Angle
	Enter		OK
	Hold		Stop / Hold
	Reveal		TV/Radio /
	Mix		Shift + Text /
	Subcode		Subtitle / EQ

